



WC200 'M' Series Roof Controller User Guide

The "**M**" Series Roof Controller is an electronic switching unit that enhances the benefits you can enjoy from your **Opening Roof**. The unique design of the "**M**" Series Roof Controller ensures easy and convenient operation of your Roof and will even memorise your preferred settings. A key feature of the unit is a **Rain Sensor** that is mounted on the roof that will automatically close all roof banks when it starts to rain.

The "**M**" Series Roof Controller operates by use of the six buttons on the switch plate. When the buttons are pushed <u>individually</u> they operate the <u>primary</u> functions of the unit. When two buttons are pressed <u>together</u>, additional <u>secondary</u> functions are operated.